

FIG. 4




FIG. 4

FIG. 2









FIG. 2



300

A curved arrow pointing from the label '300' to the central router component.




FIG. 3




FIG. 4





Fig. 5A




FIG. 5B




FIG. 6

FIG. 7A

702

700




FIG. 7A

704

706

710




FIG. 7B




FIG. 8




FIG. 9A




FIG. 9B




FIG. 9C




FIG. 10A




FIG. 10B




FIG. 11




FIG. 12




FIG. 13




FIG. 14

Internet Provider

Remote Control Home

Home Security

- ☒ Turn On Home CAM
- ☐ Turn off Home CAM
- ☒ Detect Change in Room

Security Breach In Room:

Bedroom 1 : No
Bedroom 2 : No
Living Room : Yes

View Security Breach

More Settings

Home Utilities

Temperature Control

72°F

Room Lighting:

ON OFF
Bedroom 1 ☐ ☒
Bedroom 2 ☐ ☒
Living Room ☒ ☐

WATER GARDEN:

FRONT: ☐ ☒
Time
BACK: ☐ ☒
Time

More Settings

Home Entertainment Controls

Set TV For Recording: ☒ ON ☐ OFF

Select Channel for Recording:

channel Start Time/Date
channel Start Time/Date
...
Channel Start Time/Date

More Settings




FIG. 16




FIG. 17